


OUTSIDE MOUNT

IMPORTANT! These units are manufactured to extremely close tolerance – only 1/8” smaller than the opening size given to us. Your opening must be square and “slop” is limited.

Please study the **TOP VIEW** illustration (below) carefully.

TO MEASURE: Measure the width of the daylight opening in three places and record the smallest number. Measure the height in three places and record the smallest number. When you submit your dimensions be sure to specify **OUTSIDE MOUNT** and give the smallest recorded measurements, width by height.



When measuring, it is customary to start at one end and work your way around the room, numbering openings in sequence. Upon request, we will number the units in the same order they are given to us, thus avoiding confusion at installation time.

REMEMBER: This is a tight fit! There is no inside trim; the area between the main frame and your framing/post is dressed out with a thin bead of caulking after installation. For this reason, the unit should be centered evenly within the opening.

